

# Epic Sound

## OPERATION MANUAL

### **Epic-90**

HI-FI SPEAKER SYSTEM

## ***Introduction***

---

Thank you for your business and congratulations on purchasing your Epic Sound loudspeaker system. Please follow these operational and maintenance instructions to get the most enjoyment out of your loudspeaker system.

Please take time to read through this manual carefully before setting up. It will help you to obtain the optimum performance for a long time as well as safety in use.

## ***Important Safeguards***

---

 **Caution: Read this item carefully to keep your safety.**

1. **Suffocation-** After taking the unit out of the polyethylene bag, be sure to dispose of the polyethylene bag out of the reach of children. Otherwise, they may play with the bag, which could cause hazard of suffocation.
2. **Water and moisture -**The appliance should not be used near water, bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, etc.
3. **Heat-** Do not install the unit near a source of heat, such as radiators, or under direct sunlight.
4. **Modification-** Do not attempt to open or modify the unit, for this could cause fire hazard or malfunction.
5. **Cleaning-** Do not use volatile solvents such as alcohol, paint thinner, gasoline, or benzine, etc. Use a clean dry cloth to clean the cabinet.
6. **Abnormal smell-**If an abnormal smell or smoke is detected, immediately turn the power OFF and unplug the appliance from the wall outlet. Contact your dealer or nearest service center.

## ***Removal of the Protective Speaker Grille***

---

For ultimate fidelity, we strongly recommend using speakers with the protective grilles removed during listening, although special acoustically transparent cloth is used in the grilles. As the grilles are attached magnetically, they can easily be removed by pulling them out from the cabinet.

## ***About Using Speakers Near a TV***

---

As these speakers are magnetically shielded you can place them close a TV. Note, however, that placing speakers too close a TV may in some cases cause distortion in the color reception. In such case, turn on the TV and check that color reproduction is normal. If color is distorted, turn the TV off for 15 to 30 minutes, then turn it back on and check again. (This allows the TV's degaussing circuitry to correct for the magnetic field from the speakers). If distortion is still present, move the speakers further from the TV.



# **Specifications**

---

**System.....3 way 6 speakers**

## **Loudspeaker**

**Woofers.....8 " × 1**

**Midrange.....3.5 " × 4**

**Tweeter.....1 " × 1**

**Normal impedance.....8 Ω ± 20%**

**Rated Input Power.....500W**

**Maximum Input Power.....550W**

**Sensitivity.....90 ± 3dB**

**Frequency Response.....38 ~ 20000Hz ± 20%**